



Coperion online 2-day @ 3 hrs Training for UG Polyolefin Pelletizing system

- Pelletizer operation
- · hydraulic pressure control
- adjustment to get appearance cut



table of contents

Pelletizer operation, hydraulic pressure control and adjustment to get appearance cut

- 1 General overview of the discharge equipment
 - a. What parts belong to the discharge?
 - b. Function of the start-up valve
 - c. Function of the screen pack changer
 - d. Short introduction for the die plate
 - e. Function of the pelletizer
 - i. Docking procedure
 - ii. Knife rotor
 - iii. Hydraulic system
- 2 Installation of the die plate
 - a) Alignment of the pelletizer
 - b) Grinding in procedure for the knives
 - c) die plate installation, regrinding, insulating.
 - d) fitting of pelletizer knives and the knives rotor.
 - e) thickness tolerance of the pelletizer knives.
 - f) fitting knives rotor.
 - g) adjusting pelletizer locking system
 - h) function of manual pelletizer undocking.
- 3 safety function and requirements pelltizer equipment
- 4 commissioning tests of startup and shut down sequence pelletizer equipment
- 5 safety function and requirements pelletizer equipment
- 6 interlocks pelletizer equipment
- 7 trouble shooting pelletizer equipment
- 8 Questions and customer specific topics